

STONE ARCHED NICHE AND URN



Instructions and Helpful hints for applying the Stone Arched Niche and Urn FIRST AND FOREMOST- PLEASE TAKE YOUR TIME!!!

- 1) Lay out all designs on a clean surface. Be sure to keep all protective backings on!
- 2) Cut out individual pieces for the Arched Niche. Again, keep all protective sheets on the back.
- 3) On your wall, use a yardstick, a level or a measuring tape to mark off evenly where you want the inside Niche to go. Be sure to add the extra inches for the outside grey stone area. (Arched Frame)
- 4) The first piece to be applied is the bottom of the Niche. Tape in place keeping the backing on. When you are satisfied with the positioning, take the protective backing out from behind and press down firmly from the inside out. Rub on and slowly peel the backing away.
- 5) Next, line up the Middle piece of the Niche, start with the bottom. Again make sure the protective sheet is still on. Keep in mind that it is better to let the design overlap a hair than to see a gap where the design doesn't meet.
- 6) When you are happy with positioning, take the protective sheet out from behind and apply.
- 7) Now, you can apply the Top of the Niche, again start with the bottom and make sure to keep the protective backing on until you are satisfied with the positioning.
- 8) Once in place, remove the protective sheet from behind and apply.
- 9) You are now ready to put the outside Arch Stone on. Remember to keep all of the protective sheets on until you have finished laying out all of the Arch pieces (DO NOT LET TAPE ADHERE TO ANY PIECES ALREADY APPLIED TO THE WALL).
- 10) Start with the bottom left piece. Again line up the design, keep in mind that it is better to let the design overlap a hair than to see a gap where the design doesn't meet.
- 11) Now line up the bottom right making sure that the middle crack lines up properly with the left side.
- 12) Next line up both the top left and right sides of the Arch. Remember to keep all of the protective sheets on!! Now before you rub these pieces on, make sure that the middle top piece on the Arch fits just right in between the two. Adjust the left and right pieces until it does.
- 13) Next, remove the protective backing and apply the left and right pieces followed by the final middle piece.
- 14) Finally, you can apply your urn sitting it in the middle of your niche.
- 15) Viola!! You now have a beautiful Stone Niche!! Enjoy!! ☺