

TROPICAL PORTHOLE WINDOW SCENE INSTRUCTIONAL INSERT

1. The completed Porthole will measure approximately 29" in diameter. Before placing any sheets on the wall, you need to make sure you have measured your space. **Please remember to keep the protective backing on ALL sheets until they are ready to be applied to the wall.**
2. First you will need to put up Sheet #1 – Bottom of the Tropical Porthole Scene.



3. You will then put up Sheet #2 – Top of the Tropical Porthole Scene.



4. Cut the sheets of the Tropical Porthole Window Scene Frame into the four individual pieces: Sheet 1 – Upper Left, Sheet 2 – Upper right, Sheet 3 – Lower Right & Sheet 4, Lower Left.
5. **WITH THE PROTECTIVE BACKING STILL ON**, tape all four sheets of the frame up to the wall, being careful not to place any tape on the **Tatouage that has already been transferred to the wall.** **Tape can remove transferred Tatouage!** (Fig. A) Once you know everything lines up and there are no gaps or spaces you can remove (with backing still attached) Sheets #2 -#4. Remove backing from behind Sheet #1 and apply to wall. (Fig. B)



Fig. A



Fig. B

6. Again, with the protective backing still on, you will need to tape back up Sheets 2 – 4 of Porthole Frame, making sure there are no gaps or spaces. Leaving Sheet #2 up on the wall, remove with backing Sheets #3-4. (Fig. C) Apply Sheet #2 of Frame (Fig. D).



Fig. C



Fig. D

7. With the protective backing still on tape sheets #3 & #4 of Porthole Frame to wall to check alignment, if you are sure there are no spaces or gaps (Fig E), remove Sheet #4 and apply to wall Sheet #3.



Fig. E



Fig F

8. Apply Sheet #4

